



## HP 4240/ 4250/ 4350 Fuser Installation Instructions

Please allow printer to sit for 30 minutes to cool before performing these maintenance procedures.

### Fuser Installation:

1. Turn the printer around so that the rear is facing you.
2. Remove the optional Duplexer if installed.
3. Open the rear door (output bin) and remove it by pressing on the lower left hinge. Pull it outwards to free it from the printer's frame. **(PIC 1)**
4. Firmly grasp both sides of the fuser, push the blue levers upwards to release the fuser and pull outwards. **(PIC 2)**
5. Push the new fuser in place until the blue levers on each side snap into place.
6. Install the rear door (output bin) and install the optional duplexer if removed.



**PIC 1**



**PIC 2**

### HP Maintenance Message Reset Method:

1. Turn the power off
2. Hold down SELECT, and turn printer power on. Continue holding down SELECT for several seconds, until all 3 printer control panel lights flash once, and then remain on (This may take up to 10 seconds)
3. Use (up arrow) to scroll to NEW MAINTENANCE KIT
4. Press SELECT to reset the maintenance kit counter

### ERROR CODES:

- 50.1 Low fuser temp
- 50.2 Fuser not warming up
- 50.3 High fuser temp
- 50.4 Faulty fuser
- 50.8 Low fuser temp(subthermistor)
- 50.9 High fuser temp(subthermistor)