



HP 9000 Fuser Installation Instructions

Please allow printer to sit for 30 minutes before performing these maintenance procedures.

Fuser Installation:

1. Open the left door. If the duplexer assembly is installed; remove it by pushing down on the green release lever and pulling it towards you and sliding it out of the printer.
2. Locate the fuser's left and right blue locking levers. Turn each one downwards 90 degrees to unlock the fuser.
3. Lift up on the handle slightly and pull it towards you until it is out of the printer.
4. With the blue locking levers facing downward, slide the new fuser into the printer and drop it into place.
5. Turn the blue locking levers upward 90 degrees until they snap into place.
6. Reinstall the duplex unit if it was removed in step 1.
7. Close the left door.
8. While pressing the **v** turn the printer on, when the three LEDs light depress the **?**, and then press **v** again.

ERROR CODES:

- 50.1 Low fuser temp
- 50.2 Fuser not warming up
- 50.3 High fuser temp
- 50.4 Faulty fuser
- 50.8 Low fuser temp(subthermistor)
- 50.9 High fuser temp(subthermistor)

HP Maintenance Message Reset Method:

1. Turn the printer off
2. Press and hold the CHECK key
3. Power on the printer
4. Release the CHECK key after all three lights come on. The display should read SELECT LANGUAGE
5. Press the up arrow until MAINTENANCE KIT is displayed, then press the CHECK key again and the maintenance kit count has been reset.

