



5210 / 5310

Turn the printer off, unplug it, and allow it to sit for 30 minutes before performing these maintenance steps

Fuser Installation:

1. If a duplex unit is installed, remove the printer from it by using the handholds. This may require two people.
2. Remove the fuser cover. (If you have a label printer, lift up and remove the fuser cleaner.)
3. Open the rear access door slightly and pull up at a slight angle to remove.
4. Loosen the two screws on the redrive unit; remove the redrive unit by pulling outward by the tabs.
5. Loosen the two screws on the fuser assembly and pull the fuser from the printer; to do so, pull the fuser by the metal tab.
6. Install the new fuser in reverse fashion.

ERROR CODES:

913 Paper Jam May have bad sensor

920 Low fuser temp

921 Low fuser temp

922 Low fuser temp

923 High fuser temp

924 Open circuit to thermistor Check connections

925 Wrong Fuser Model

TO CLEAR THE '80 SCHEDULED MAINTENANCE' MESSAGE AND RESET THE MAINTENANCE PAGE COUNT PERFORM THE FOLLOWING STEPS.

1. Turn the printer power off.
2. While pressing and holding SELECT and RETURN turn the printer power on. Press GO and CONFIG MENU will appear on the display.
3. Press and release MENU>or<MENU until RESET MAINT CNT appears on the second line of the display.
4. Press SELECT twice to reset the counter.
5. Turn the power off and the printer is ready to resume operating.

